

LINHA BRAILLE COMPLETA

Linha Braille



Medidas:



- BRC101B
- BRC101P
- BRC101A



- BRC102B
- BRC102P
- BRC102A



- BRC103B
- BRC103P
- BRC103A



- BRC104B
- BRC104P
- BRC104A



- BRC105B
- BRC105P
- BRC105A



- BRC106B
- BRC106P
- BRC106A



- BRC107B
- BRC107P
- BRC107A



- BRC108B
- BRC108P
- BRC108A



- BRC109B
- BRC109P
- BRC109A



- BRC110B
- BRC110P
- BRC110A



- BRC111B
- BRC111P
- BRC111A



- BRC112B
- BRC112P
- BRC112A



- BRC113B
- BRC113P
- BRC113A




- BRC114B
- BRC114P
- BRC114A



- BRC115B
- BRC115P
- BRC115A

INFORMAÇÃO DE USO

Veja como instalar as placas conforme as indicações de distância e altura segundo a NBR 9050:2015.



Para outros itens ou situações, consultar a NBR 9050:2015 e profissional habilitado.